

**1**

4 x  
4 x

SCREW THE FOUR LARGE PINS ON THE TOP SIDE

**2**

5 x

MOUNT THE TOP OF STACKING KIT ON BLAST CHILLER AND FIX IT ON THE BACK SIDE WITH THE PROVIDED SELF-DRILLING SCREWS (5pcs)

UNSCREW THE FEETS FOR ABOUT 5mm ON THE RIGHT SIDE

**3a**

10 x  
10 x

MOUNT THE 5 SCREW GROMMETS AND FIX THE RIGHT PANEL WITH PROVIDED SCREWS (5pcs)

MOUNT THE RIGHT PANEL AND FIX THE FEETS ON THE BASEMENT TOGETHER WITH THE RIGHT PANEL

**3b**

REPEAT 3a FOR LEFT SIDE